



KZ mätarbrunn - dimensioneringstabell

Mätarens storlek		Antal mätare	Flerbostadshus, antal lägenheter	Enbostadshus, antal hus per grupp
Q ₃ 4	Qn 2,5	1	1-8	1-7
Q ₃ 4	Qn 2,5	2	9-30	8-26
Q ₃ 4	Qn 2,5	3	31-60	27-50
Q ₃ 4	Qn 2,5	4	61-90	51-80
Q ₃ 10	Qn 6	1	9-40	8-35
Q ₃ 10	Qn 6	2	91-110	81-100
Q ₃ 10	Qn 6	3	111-200	101-170
Q ₃ 10	Qn 6	4	201-280	171-250
Q ₃ 16	Qn 10	1	41-90	36-75
Q ₃ 16	Qn 10	2	91-220	76-200
Q ₃ 16	Qn 10	3	221-380	201-330